

MAKE THE
WORLD SEE

Milestone Systems

XProtect® Rapid REVIEW 2024 M1

Installation and deployment guide



Contents

Copyright, trademarks, and disclaimer	4
XProtect Rapid REVIEW 2024 M1	5
Installation and deployment steps	6
Prerequisites	6
STEP 1 - Run the Installer	8
Firewall Consideration and Ports Availability	17
Installation Troubleshooting	18
Activate licenses	19
Licensing warning	19
Online activation	19
Offline activation	21
Activate via the BriefCam License Activation application	22
Activate via the Gemalto application.	23
System expansion (adding additional device licenses)	24
STEP 2 – Set up the deployment	25
STEP 3 – Define and activate the cameras	29
STEP 4 – Disable face recognition and license plate recognition (optional)	32
STEP 5 – Install BriefCam Embedded Client for Milestone XProtect plug-in	32
STEP 6 - Install BriefCam's management client plug-in (optional)	36
STEP 7 – Using an HTTPS host (optional)	37
Recommendations	38
Prerequisites	38
Steps	38
NGINX Windows Service	44
Generic configurations	45
Logging	45
Network security considerations	47
Upgrade Steps	47
License upgrade	49
Apply the V2C File	49

Restart Services and clear the cache	50
Non-administrator users	50
Troubleshooting	51
Failed fetching camera plugins error	51
Symptom	51
Possible root causes	51
Solution	52
White screen displayed	54
Symptom	54
Possible root causes	55
Solution	55
Missing license	60
Environment settings not configured properly	60
Server unavailable error	61
Symptom	61
Possible root causes	62
Solution	62
Server returned 401 Unauthorized error	64
Rapid REVIEW tab is missing	64
Symptom	64
Possible root causes	64
Solution	64
Rapid REVIEW tab is not appearing correctly	65
APPENDIX: XProtect Rapid REVIEW 2024 M1 hardware recommendations	66
All-in-One configurations	66
Throughput example	68
RAID redundancy	68
Larger deployments	68
Supported Graphical Processing Units (GPU)	68
Other GPUs	69

Copyright, trademarks, and disclaimer

Copyright © 2024 Milestone Systems A/S

Trademarks

XProtect is a registered trademark of Milestone Systems A/S.

Microsoft and Windows are registered trademarks of Microsoft Corporation. App Store is a service mark of Apple Inc. Android is a trademark of Google Inc.

All other trademarks mentioned in this document are trademarks of their respective owners.

Disclaimer

This text is intended for general information purposes only, and due care has been taken in its preparation.

Any risk arising from the use of this information rests with the recipient, and nothing herein should be construed as constituting any kind of warranty.

Milestone Systems A/S reserves the right to make adjustments without prior notification.

All names of people and organizations used in the examples in this text are fictitious. Any resemblance to any actual organization or person, living or dead, is purely coincidental and unintended.

This product may make use of third-party software for which specific terms and conditions may apply. When that is the case, you can find more information in the file `3rd_party_software_terms_and_conditions.txt` located in your Milestone system installation folder.

XProtect Rapid REVIEW 2024 M1

This installation and deployment guide outlines the installation and deployment of XProtect Rapid REVIEW for rapid time-to-value.

Get started and accelerate investigations with XProtect Rapid REVIEW

- Review hours of video in minutes with VIDEO SYNOPSIS®
- Pinpoint objects of interest with robust multi-camera search capabilities supporting 29 classes and attributes, face recognition, appearance similarity, color, size, speed, path, direction, and dwell time
- Quickly and effectively organize all video assets of an investigation with collaborative case management
- Rapidly visualize activity level, dwell time, common paths and background changes with powerful visual layers

Installation and deployment steps

1. Run the installer
2. Set up the deployment
3. Define and activate the cameras
4. Disable face recognition and license plate recognition (optional)
5. Install BriefCam Embedded Client for Milestone XProtect plug-in
6. Using an HTTPS host (optional)

Prerequisites

Before you install, please check the following list of prerequisites.

Server	At least one dedicated server for XProtect Rapid REVIEW (it cannot be installed on the same server with the VMS).
Memory	At least 128GB of RAM
Storage	<ul style="list-style-type: none"> • At least 250GB of free space for the application • At least 250GB for the database (on SSD drives) • At least 500GB drive for data storage (video and metadata) <p>Refer to the APPENDIX: XProtect Rapid REVIEW 2024 M1 hardware recommendations on page 66 for recommended storage size.</p>
GPUs	<p>At least one supported GPU. For additional information, see the list of recommended GPUs which is available on the specification sheet that you can download from the Milestone Content Portal: Collections / Rapid REVIEW.</p> <p>The GPU should not be used for any system task such as connecting a monitor to the GPU or running applications, such as Chrome, using the GPU.</p>
CPU	For each GPU, at least 8 cores at base (non-turbo) frequency of 2.5GHz and above.
Drivers	<p>For the server with the GPU, make sure to download a supported version of the NVIDIA driver (470.94 or higher).</p> <p>Make sure to restart the computer after installing the NVIDIA driver.</p>

Network connectivity between BriefCam and the VMS	Ensure a minimum of 1 Gbps of throughput is available. This is relevant for deployments with less than 300 cameras on site. For larger deployments, consult with your BriefCam Account Manager.
Operating System	Windows 11, Windows 10 Pro version 1803 or higher, Windows Server 2022, Windows Server 2019 or Windows Server 2016 (you can check the Windows versions by running winver.exe.) Windows 11 and Windows 10 Pro (version 1803 or higher) can be used for development environments or all-in-one production environments with a single GPU without the RESEARCH component. They are not supported for other production environments and are not supported for any RESEARCH environment. Windows OS must be in English (Get-WinSystemLocale command in Powershell)
Windows Updates	Make sure that the latest Windows updates are installed.
.NET Framework	If the computer is running Windows 10 or Windows Server 2016, download and install .NET Framework 4.7.2 Runtime or higher. Make sure to restart the computer after installing .NET Framework.
Permissions	Current logged in user has full local admin rights and full Registry Read/Write permissions.
Browsers	Mozilla Firefox version 69.* and above Google Chrome version 77.* and above Microsoft Edge version 80 and above
Ports	See the Firewall Consideration and Ports Availability section below.
UAC (User Account Control)	The Windows User Account Control must be disabled.
VSServer service	The user that will run the BriefCam VSServer service must be a local administrators and also a member of the IIS_IUSRS service group in Active Directory.

STEP 1 - Run the Installer



XProtect Rapid REVIEW will not work if the minimum requirements are not met. For additional information, see the [APPENDIX: XProtect Rapid REVIEW 2024 M1 hardware recommendations on page 66](#).

1. Extract the XProtect Rapid REVIEW package (RapidREVIEW <version>.zip).

The extracted folder includes the XProtect Rapid REVIEW installer, multiple BriefCam installer files and an installation and configuration guide. You do not need to run any of the BriefCam installers (except for the NGINX, embedded client, and management client installers at a later stage).

Name	Date modified
MilestoneXProtectRapidReview2024M1Installer_7.0.37096.exe	06/06/2024 09:28
LICENSE.pdf	06/06/2024 09:28
config.json	06/06/2024 09:28
BriefCamWebServices_7.0.37096.exe	06/06/2024 09:27
BriefCamServer_7.0.37096.exe	06/06/2024 09:28
BriefCamRabbitMQ_7.0.37096.exe	06/06/2024 09:27
BriefCamPostgreSQL_7.0.37096.exe	06/06/2024 09:27
BriefCamNGINX_7.0.37096.exe	06/06/2024 09:27
BriefCamMilestoneXProtectManagementClientPlugin_7.0.37096.exe	06/06/2024 09:27
BriefCamMilestonePlugin_7.0.37096.exe	06/06/2024 09:27
BriefCamEmbeddedClientForMilestoneXProtect_7.0.37096.exe	06/06/2024 09:28



BriefCam uses port 80 for its application. If you want to use a different port, change it in the config.json file before running the installer. The **config.json** file is one of the files in the installation package.

2. Right-click the MilestoneXProtectRapidReview2023R2M1Installer_7.0.37096.exe file and select **Run as administrator**.
3. Read and accept the License Agreement terms and click **NEXT**.




When running on a laptop, you may also see a duplicated smaller screen on top of the regular installation screen. To continue, check the check box on the smaller screen and the NEXT button on the larger screen. This is a known issue


4. The installer will check to see if your computer meets the minimum prerequisites..

- If all the prerequisites are met, you'll see a "Your system is fine" message.
- If any of the prerequisites are not met, you will see a screen describing the warnings. Try resolving the warnings (for more information see the [Prerequisites](#) section) and then click **RETRY** or run the installer again. To resolve the warnings, you can also see the logs and run the standalone Check Prerequisites tool.

If there are still errors and you click NEXT, the installation will continue. However, may not run properly on your computer since it does not meet the minimum requirements.



5. Select whether you want to install, upgrade, or uninstall XProtect Rapid REVIEW.



If you select **INSTALL** or **UPGRADE**, the following screen appears.



6. Click **NEXT**.

The following screen opens where you'll enter the necessary credentials and settings.

✕

Define user names and passwords

These are all required arguments.

BriefCam account settings

i **BriefCam User**
A user that runs BriefCam services

Password
Password for the BriefCam User

PostgreSQL BriefCam user


i **Database User**
BriefCam application user for the database (PostgreSQL)


Database Password
Password for the Database User

[Advanced settings](#)

7. Fill in the following fields. (You can click the **Simple mode** option if you only want to show required fields.)

Field	Description
BriefCam account settings (required)	
BriefCam User	The Windows user that runs the services. If this user does not yet exist, the installer will create it for you.
Password	<p>The password of the user above (BriefCam User). Note that apostrophes and double quotes are not supported in the Password field.</p> <p>Use a password that is compliant with your organization’s password policy.</p> <p>A password may fail for a variety of reasons:</p> <ul style="list-style-type: none"> • The password does not meet the password policy of the operating system and/or organization. • Domain accounts cannot be created using this dialog. Contact the relevant IT person if a new domain account is required. • If the user is disabled, locked, or otherwise limited.
Database admin settings	
Database Admin User	The admin user for the PostgreSQL database. This cannot be the same as the Database User in the table above.
Database Admin Password	The password of the user above (Database Admin User). A database admin password is automatically generated. Note that apostrophes and double quotes are not supported in the Database Admin Password field.
PostgreSQL BriefCam User (required)	
Database User	<p>The PostgreSQL user that accesses the application database.</p> <p>Note that the user name is case sensitive.</p>
Database Password	The password of the user above (Database User). Note that apostrophes and double quotes are not supported in the Database Password field.
Authentication key	
Passphrase	This passphrase will be used to generate an encryption key to secure connection

	strings and other sensitive data.
Domain Name	
Domain Name	If the user is a domain user, enter the domain name and make sure that the domain user has full admin privileges on the server. If the user is a local user, enter a period (.). Note that the domain name is case sensitive.
License activation key	
Software activation key	<p>The license activation key provided by Milestone.</p> <p>The license will be activated if the computer is online. If it is not online, you can activate the license using the BriefCam License Activation tool, which you can access by clicking the following icon after the installation completes.</p> 
Paths	
Root path	The path where you want to install BriefCam.
Shared directory	<p>The drive that will be the shared data folder. This folder will store longer blobs, database backups, rendered synopsis files, and more.</p> <ul style="list-style-type: none"> • It's recommended to select the drive with the most available space. • The path to the PostgreSQL data cannot contain special characters, such as space, ~, and &. • If you select an existing shared network folder, make sure that the user has permissions to the shared network folder. • If you want to select a mapped drive, make sure to first map the drive before installing BriefCam. <p>In the properties of the drive you select, make sure that you unchecked the</p>

	<p>Allow files on this drive to have contents indexed in addition to file properties check box (as shown in the image below).</p> 
<p>Postgres data directory</p>	<p>The path where you want to store PostgreSQL data. This path must be set to an SSD drive. This field cannot contain special characters, such as space, ~, and %.</p>
<p>Milestone</p>	
<p>MilestoneSSO Provider</p>	<p>Leave as-is. The endpoint of the Rapid REVIEW-Milestone integration service.</p>
<p>Milestone VMS Address</p>	<p>If you already want to configure the connection to the MilestoneVMS, enter the host or IP address of the Milestone VMS in this field. It is recommended to fill it in.</p>

8. Click **NEXT** and a summary screen will appear.

BriefCam X

It is recommended to copy and save the data for future use. The data will not be available after this screen is closed. [COPY](#)

BriefCam account settings

BriefCam User **Sergey**

BriefCam Password *****

Database admin settings

Database Admin User **Shahar**

Database Admin Password *****


PostgreSQL BriefCam user


Database User **Shahar**

[BACK](#) [NEXT](#)

9. Review the settings and save the settings for future use by clicking the **COPY** button.
10. Click **NEXT** to complete the installation.

The installation may take 10-25 minutes. Note that after the installation is complete, the services will be automatically restarted.



 If you did not fill in the VMS address after the installation completed, open the **MilestoneSSOProvider.exe.config** file and update the **MilestoneAddress** value to the VMS address.

By default, this file is located in C:\Program Files\BriefCam\BriefCam Server.

Firewall Consideration and Ports Availability

Internal (Local) Ports

On each server, the following ports should be opened for internal communication:

- On each server, all outbound ports should be opened, to allow communicating with other servers as needed.
- On each server, the following inbound ports should be opened according to the installed services. The BriefCam application listens for incoming traffic from these ports. The installer will create the relevant Windows firewall rules for these ports.

Component	Port #
BI Face Recognition Service	TCP 13004
Face Recognition Matching Service	TCP 13002
Filtering Service	TCP 13001
License Service	TCP 1947
Lighthouse Service	TCP 2553, TCP 2554, TCP 2555, TCP 2556, TCP 2557
LPR Matching Service	TCP 13003
Milestone	TCP 554, TCP 8080
MilestoneSSOProvider	TCP 8030
Notification Service	TCP 7080
PostgreSQL Redis	TCP 5432
Redis	TCP 6379
Storage	TCP 139, TCP 445
Video Streaming Gateway Service	TCP 5010

VSServer Service	TCP 1112, TCP 1113
Web Services (BOA, ProWebApi, AdminWebApi)	HTTP (80)

External Ports

The following ports should be opened to traffic coming from the end users' browsers.

Component	Port #	Comment
Web Services	HTTP (80)	
Video Streaming Gateway Service	TCP 5010	Not needed when using a load balancer
Notification Service	TCP 7080	

Additionally recommended prerequisites

- Set the default system language to English during the installation. If the language is a language other than English, the installation may end with an error. The system language can be set to any preferred language after the installation.
- Disable antivirus scans from all BriefCam folders. For more information, see the [Antivirus guidelines](#) from BriefCam.

Installation Troubleshooting

If the installation failed:

1. Investigate the log files (**deploy.log** and the **MilestoneXProtectRapidReview2023R2Installer_<version>.log**) to see which component of the installation has failed. The log files are in the folder where you extracted the installation files.
2. Investigate the relevant component's log file and fix the issue according to the error in the log.
3. Uninstall Rapid REVIEW using the **UNINSTALL** option in the installer.
4. Restart the computer.
5. Reinstall Rapid REVIEW.

Activate licenses

This information assists you in activating an XProtect Rapid REVIEW license. You can complete activation in both online and offline modes.

It also assists you in modifying and re-activating an existing license for system expansion if, for example, you want to add additional device licenses.



All steps listed below should be performed on the server where you installed XProtect Rapid REVIEW.

Licensing warning

Be aware that licensing with BriefCam is sensitive. A product key can be activated only once. If you try to activate it again, it will fail with error code 831. Furthermore, if certain components are missing on your BriefCam installation, there is a chance that the license is activated on the BriefCam licensing server without being applied on your system. If this happens, you must open a support case with BriefCam requesting an extra activation for the license.

To prevent problems with license activation:

- Make sure that the **Sentinel LDK License Manager** service is available in Windows Services.
- Verify that you can access the URL <http://localhost:1947> to get to the GEMALTO application site.
- All IIS AppPools must be in place: AdminApiPool, AdminClientPool, BoaPool, ProWebApiPool, ProWebApiStoragePool, ProWebClientPool, VideProcessingGateway
- All BriefCam components must be available in Control Panel – Programs: BriefCam PostgreSQL, BriefCam Web Services, BriefCam Server, BriefCam Milestone Plugin.


If any of the preconditions mentioned above are not accomplished, please open a case with Milestone Technical Support providing your license product key and tag ID.

Once the license is activated successfully, you can uninstall and re-install as many times as you wish. The license will remain on the server so you don't need to re-activate it. A request for an extra activation for the license will only be required in the case of a re-installation of the Windows OS or if the license is deleted by a disk formatting .


Online activation

Online activation requires an active Internet connection.


1. From the desktop, do one of the following
 - Click the BriefCam License Activation application.




- From the **Start** menu, type **BriefCam License Activation** and launch the application.



2. Enter your product key and click **Activate**.



When the activation is successful, the following dialog box will appear. Here you'll find your Tag ID, which you'll need when you open a [support ticket](#).




3. Click **OK** to close the dialog box and then click **Close** in the main application window to close the License Activation application.

Offline activation


Offline activation is useful in cases where internet connectivity is not available on the computer where you are installing BriefCam.

To perform offline activation:


1. From the desktop, do one of the following:
 - Click the BriefCam License Activation application.




- From the Start menu, type **BriefCam License Activation** and launch the application.



- Click the **Offline** tab to access offline activation.



2. Click **1. Collect Information** to generate a C2V (client to vendor) file, select or approve the destination in which it is to be stored, and click **Save**.




3. Send the C2V file to the Support team by logging into [Milestone Support](#) to open a ticket and attaching the C2V file. The product key number you received from Milestone needs to be mentioned in the ticket. This will help the support team generate the relevant V2C file (vendor to client), which is required to activate the product offline.

After receiving the V2C, there are two ways to activate the product offline:

You can activate via the BriefCam License Activation application or you can use the Gemalto application.

Activate via the BriefCam License Activation application


1. Open the BriefCam License Activation application.
2. Click the **Offline** tab.
3. Click **3. Apply license**.
4. Select the V2C file provided by the [support team](#), and click **Open**.



5. When you see a message that the product was activated successfully, click **OK** and close the License Activation application. BriefCam will now be activated.

Activate via the Gemalto application.


1. Open a web browser.
2. Open http://localhost:1947/_int_/checkin.html.
3. Select the **Update/Attach** option.
4. Click **Choose File**.
5. Select the V2C file provided by the support team.
6. Click **Apply File**.



System expansion (adding additional device licenses)

To make any modifications to the license, such as adding cameras to the license, you need to:


1. Activate the license.
2. Place an order and mention the system Tag ID and the Key ID, which can be found in the Gemalto application:
 - a. Open your browser.
 - b. Go to the [Sentinel Admin Control Center](#)
 - c. Copy the Key ID.



The Milestone team will then generate the relevant V2C with the requested modification(s).

3. Activate the V2C on the server:
 - a. Open a web browser.
 - b. Go to the [Sentinel Admin Control Center](#).
 - c. Select the **Update/Attach** option.


- d. Click **Choose File**.
- e. Select the V2C file provided by the Milestone support team.
- f. Click **Apply File**.





STEP 2 – Set up the deployment

1. In a browser, enter the hostname of the computer where XProtect Rapid REVIEW was installed followed by slash (/) and the word **admin**, that is: **http://[computer name]/admin**. The BriefCam Administrator Console will open.
2. Log into the console. The initial administrator is **Administrator** and the password is **changeit**.
3. Change the password.


You'll now set up the deployment from the **Deployment** section.




4. From the **Deployment** section, click **Hosts**.
5. Next to the host name, click on the settings icon .
6. From the **Templates** menu, select **All In One**.




7. Clear the **Alert Processing Server**, **BI Face Recognition Service**, and **BI Rule Engine Service** check boxes (these options will not be needed).
8. Click **Apply**.
9. From the **Deployment** section, click **GPUs** and then select **GPU OX5**.

- 10. Click on the edit icon ().
- 11. If face recognition will be used, select the **Face Recognition** check box.
- 12. In the **Mode** column, select **On Demand**.




- 13. Verify that the number of workers under **Workers** is set to 4.
- 14. From the **Deployment** section, click **Services**.
- 15. Select the check box at the top left of the table.
- 16. Click the start button.



STEP 3 – Define and activate the cameras

1. Open the **Settings** section and click **Camera Management** (as shown in the image below).



2. Click **Add directory**. The **Add Directory** dialog box opens.


The screenshot shows a dialog box titled "Add Directory" with a close button in the top right corner. Below the title bar, it says "Fill in the fields below". There are five input fields:

- Video Integration ***: A dropdown menu with "Milestone Integration" selected.
- Directory Name ***: A text field containing "Milestone".
- Address ***: A text field containing "[VMS IP Address]".
- User Name ***: A text field containing "admin".
- Password**: A text field with masked characters "****".


At the bottom of the dialog, there are two buttons: "Cancel" on the left and "Add" on the right.

3. From the **Video Integration** field, select **Milestone Integration**.
4. In the **Directory Name** field, enter a display name for the user directory.
5. In the **Address** field, enter the IP address of the Milestone VMS server.
6. In the **User Name** and **Password** fields, enter an administrator user name and password of the VMS server. With an admin user you can make sure that all the cameras can be accessed.
7. Click **Add** to add the directory.


- Click the zoom (⋮) icon to the right of the new directory and select the **Add / Edit Cameras** option.



- For all of the cameras, select the check box in the camera's **Activated** column and click the **Activate** button (located in the bottom right corner), as shown in the image below.



10. The **Camera Activation** pane shown below will appear. If you are sure you want to activate the cameras, click **Yes**. Note that Camera activation is irreversible. It cannot be reset unless a special approved request is opened with BriefCam support.



STEP 4 – Disable face recognition and license plate recognition (optional)

If you want to disable face recognition and/or license plate recognition:

1. In the BriefCam Administrator Console, open the **Settings** section and click Environment Settings
2. Set the **clientEnableFaceRecognition** environment setting to **false**. This removes the Face Recognition functionality from the UI.
3. Set the **MetaData.EnableFaceRecognition** environment setting to **false**. This disables the Face Recognition engine.
4. Set the **EnableLPR** environment setting to **false**. This removes the License Plate Recognition functionality from the UI.


STEP 5 – Install BriefCam Embedded Client for Milestone XProtect plug-in




When using the embedded client, BriefCam can only work with a single Milestone VMS.

On each XProtect Rapid REVIEW client computer, install BriefCam’s embedded client for Milestone XProtect plugin.


1. Click the **BriefCam Embedded Client for Milestone XProtect** plug-in file to download it and then run it. You'll find the plugin in the XProtect Rapid REVIEW zip file.
2. The installation checks for prerequisites, such as Microsoft .NET Framework 4.7.2 Full and Microsoft Visual C++ 2015 2017 2019 Redistributable Package (x64).
3. If anything is missing, you will be prompted to install the missing prerequisites and click **Install**.
4. In the Welcome screen, click **Get Started**.
5. Read the license, accept the License Agreement terms, and click **Next**.
6. Select the installation destination path and click **Next**.
Note that the installation path must be the same directory where **Milestone XProtect Smart Client** is installed. (This may vary slightly between client computers and between Milestone versions.)
7. Select XProtect Rapid REVIEW and click **Next**



8. Enter the BriefCam Web Application URL (which is the hostname or IP address of the BriefCam computer followed by **/synopsis** and verify that the provided URL is correct by clicking the **Verify URL** button (as shown below).



9. In the **BriefCam Open API (BOA) Server Address** field, enter the hostname or IP address of the BriefCam computer followed by **/BOA**.
10. Click **Next**.
11. Click **Install** and then click **Finish**.
12. In the BriefCam Administrator Console, restart the services by selecting all of the services, clicking the stop button (■) and then the start button (▶), as shown in the image below.




13. Restart IIS on the Rapid REVIEW server by opening the Windows services and right-click the **World Wide Web Publishing Service**. Then click **Restart**.




Note: An admin user is automatically created by the SSO when logging into the Milestone client using the **Basic authentication** or **Windows authentication** method.

If you want to log into the Milestone client using the **Windows authentication (current user)** option, add the **BriefCam user** that you used to install BriefCam services to the **Administrators** group in Milestone XProtect Management Client.



When you have completed the steps, a **BriefCam** tab will appear in the Milestone XProtect Smart Client.




In BriefCam, for security reasons, users are automatically logged out if no activity is detected for 20 minutes. Therefore, a user may be automatically logged off the BriefCam functionality while the Milestone VMS is still running.

STEP 6 - Install BriefCam's manangement client plug-in (optional)


If you want non-administrator users to be able log into the Milestone system and see BriefCam, install BriefCam's management client for the Milestone plug-in on the computer where Milestone's XProtect management client is installed.

Note, that once the management plug-in is installed and configured, reverting to a configuration without this plug-in is not possible.


1. Click on the BriefCam Milestone XProtect management client plug-in file to download it and then run it. You'll find the plug-in in the XProtect Rapid REVIEW zip file.
2. In the Welcome screen, click **Get Started**.
3. Read the license, accept the License Agreement terms, and click **Next**.
4. Select the installation destination path and click **Install**.
5. Log into the Milestone XProtect management client .
6. Right-click on the **Roles** section and add a new role, for example: BriefCam users as shown in the image below.
7. Make sure that the new role is selected and click the BriefCam tab at the bottom of the screen. In the management client in Milestone XProtect 2023 R1, the tab is named **MIP**.



8. From the **Role Settings** section, select the BriefCam role, as shown in the image below.
9. Give these users access to BriefCam by selecting the **Allow** access to video analytics platform checkbox.



If the check box is not selected, the user will see the following message when clicking the **Rapid REVIEW** tab. If the check box is not checked, the user will see the following message when clicking the **Rapid REVIEW** tab.



STEP 7 – Using an HTTPS host (optional)



To work with SSL and BriefCam, using a load balancer is required.

This section describes the steps to take to use the NGINX load balancer as an https host for BriefCam services.

Recommendations

- BriefCam recommends using NGINX.
- It is recommended to use NGINX. You'll find BriefCam's NGINX plugin in the XProtect Rapid REVIEW zip file.
- It is recommended to use NGINX. You'll find BriefCam's NGINX plug-in in the XProtect Rapid REVIEW zip file.
- If you are working in a virtualized environment, the load balancer must be on a separate machine.
- If you are working in a non-virtualized (physical servers) environment, you can have the load balancer on the same machine as the Web Services (although it is not recommended). However, if you install the load balancer on the same machine as the Web Services, IIS has to work on a different port than 80, since 80 is for NGINX.


Prerequisites

- Make sure that port 80 is not in use by another application.
- If IIS is installed, make sure to stop it or change its default port.

Steps

1. To run BriefCam's NGINX Installation wizard, right-click on the BriefCamNGINX_<Version number>.exe file and select **Run as administrator**.

If you are using the latest Windows Update and a Windows Defender alert appears, click the **More info** link and click **Run anyway**.



2. In the Welcome screen, click **Get Started**.
3. Accept the terms of the BriefCam license agreement and click **Next**.
4. Read the license agreement and click **Next**.

5. Enter the IP address or the hostname (if there is a DNS resolution) for each of the relevant services below, and click **Next**.

BriefCam Install NGINX

Services Configuration

Internal Port: The actual port a particular service listens to
Port: The port NGINX listens to


Use New Storage Service

Research	<input type="text"/>	Internal Port	<input type="text" value="8090"/>		
Notification	<input type="text"/>	Internal Port	<input type="text" value="7080"/>		
Video Streaming	<input type="text"/>	Internal Port	<input type="text" value="5010"/>		
Web Services	<input type="text"/>	Internal Port	<input type="text" value="80"/>		
Processing	<input type="text"/>	Port	<input type="text" value="49149"/>	Internal Port	<input type="text" value="5002"/>
VMS Agent	<input type="text"/>	Port	<input type="text" value="49151"/>	Internal Port	<input type="text" value="1120"/>
Visual Assets	<input type="text"/>	Port	<input type="text" value="49251"/>	Internal Port	<input type="text" value="5011"/>
Storage Service	<input type="text"/>	Internal Port	<input type="text" value="5012"/>		

6. Decide whether to run with a secure communication.

7. If you select the check box, enter the paths to the certificate and private key.


You need to create or use an existing self-signed certificate separated into two files: .crt and .key.



8. If your SSL certificate is protected by a password, you need to configure NGINX to read a list of passwords that are stored in a separate file. If the private key is not in this file, NGINX will not start. You do this as follows:
 - a. Create a new text file named `ssl_passwords.txt` and save it to a separate folder than where the SSL certificate is located.
 - b. Set the file to be readable only to the user running NGINX.
 - c. Enter the certificate password into the first line of the `ssl_passwords.txt` file.
 - d. In the nginx config file, add the following line above the existing certificate lines:


```
ssl_password_file /var/lib/nginx/ssl_passwords.txt;
```
 - e. Distribute this file separately from the configuration file.

For additional security measures for SSL private keys, see the NGINX documentation.




9. Click **Next**.
10. In the **Database Host** and **Database Port** fields, enter the name and port of the machine where you installed PostgreSQL.
11. In the **Application User** and **Application Password** fields, enter the username and password that you entered when installing PostgreSQL.
12. Click the **Test Database Connection** button.

13. Click **Next**.
14. Confirm or select the drive where you want to install NGINX and click **Install**.
15. If you have more than one web service hostname, after installing NGINX, open the `nginx.conf` file (located by default at: `C:/nginx/conf`) and in the `http` section, copy and paste the existing rows and update the new rows with the additional hostnames.
16. On any host that is running the application (browser) make sure the domains (or host name) can be resolved by the DNS. If no DNS is available, you can edit the `hosts` file and add the IP address of the load balancer using the following syntax:
 - `10.x.x.x www.example.com example.com`
For example: `10.0.0.143 www.example.com`
17. Open the following three web config `.js` files on the BriefCam server (by default these three files are at `C:\Program Files\BriefCam\WebServices`):
 - `\app\webConfig.js`
 - `\ProWebAdminClient\web.config.js`
 - `\ProWebClient\webConfig.js`




18. In each of the three web config .js files, set the endpoints (**endPointApi**) to point to the load balancer. In the example below, you would change **PRODUCT1** to the address to the load balancer. Make sure that "http:" does not appear in the path.



```
web.config - Notepad
File Edit Format View Help
const endPointApi = '//'PRODUCT1/AdminApi/";
```


19. Open the QLIK QMC with the user that was used to install the RESEARCH module (https://<hostname>/qmc).
20. Browse to virtual proxies and add two new parameters using the hostname of each of the machines (for example, the QLIK machine and the NGINX machine host names as shown in the image below) to both proxies:
 - Virtual Proxies->bc->advanced->Host white list
 - Virtual Proxies->Central Proxy (Default)->advanced->Host white list

 On some systems, you might be required to add the host name, FQDN and IP address of the load balancer and all the web services instances into the virtual proxies white list in QMC.

21. Check that the follow environment settings are set to the NGINX IP address or hostname and if you selected to use a secured connection (https), make sure the URLs begin with https:
 - BaseVideoUrl.
 - clientNotificationEndPoint
 - DB.LocalStorageAddress
 - LoadBalancerAddress – This setting should be set to: <NGINX-IP>
 - ProWebApiAddress
 - ProWebClientAddress
 - QlikServer
 - Site.Url
 - StorageGatewayUrl
 - SSOEndpoint – If you want to use an embedded client, this value should be set to:
https://<NGINX-host>:8030/MilestoneSSO/
 - VideoProcessingGateWayUrl–ThisisonlyneededifyouareusingtheStorageGatewayService.
22. Restart the BriefCam services.
23. If you selected to use a secured connection (https), browse to the application and check that it works with https requests. For example:
 - https://www.example.com/app
 - https://www.example.com/admin

NGINX Windows Service

The BriefCam NGINX installer creates a **BriefCamNGINX Web Server** service in the Windows Services screen. This service is responsible for making sure the NGINX process is constantly running and the load balancer is ready to accept requests.



Generic configurations

For any other type of load balancer, you need to configure the following redirect rules based on the URL:


1. Notification Service
Search for: /signalr
Redirect to: notification-server:7080
2. Video Streaming Gateway
Search for: /vsg
Use rewrite rule to remove /vsg from the url
Redirect to: videostreaming-server:5010
3. Web Services>
Search for: /
Redirect to: briefcam-webserver

Logging

To handle the log rotation:


1. Download the log rotation text from here: [Log rotation script](#) and create a bat file:
 - a. Copy the text from the link to a .txt file and name it LogRotation.
 - b. Change the file extension from .txt to .bat.
2. Save the script (.bat file) to C:\NGINX.

3. Create an OS user (such as **bcuser**), a user on the OS level, or create a Windows user account. The user does not need admin rights.
4. Edit the C:\NGINX folder's security options and assign full control to the user that you created in step 3.
5. Click **Start** (Windows key) and type **secpol.msc** to open the **Local Security Policy** utility.



6. Go to **Security settings > Local Policies > User Rights Assignment**.
7. Right-click **Log on as a batch job** and add the user.
8. Add a daily scheduled task to run the C:\NGINX\LogRotation.bat file. Make sure to select **Run whether user is logged on or not**. By default, the last 10 days will be retained (retention period in days). If you want a different number of days, when running the batch file, enter the required number of days as a command line argument. For example, for 20 days, use: C:\NGINX\LogRotation.bat 20.

Network security considerations




- The network segment hosting the BriefCam servers / virtual computers should be separated from other networks by a firewall and access should be granted only via ports configured in NGINX. For additional information, see the [Using an HTTPS Host](#).
- Administrative access to the servers, such as RDP, should be allowed either over VPN or from administration bastion hosts. A bastion host is a server that allows access to a private network from a public network, such as the internet. Bastion hosts are vulnerable to potential attacks and should be kept as secure as possible.
- If DPI / WAF / URL protection are required – they should be implemented on the firewall when pointing to the operational BriefCam NGINX host.

Upgrade Steps

To upgrade XProtect Rapid REVIEW, select the **UPGRADE** option on the installer screen as shown below.


Note that using this installer to upgrade XProtect Rapid REVIEW, you can only upgrade from version 6.4 and above:



1. Stop all BriefCam services and close all open applications before starting the upgrade process.
2. Select the **UPGRADE** option on the installer screen.
3. If you are upgrading, the tab name will not show Rapid REVIEW. To change the tab name, open the **BriefCam.MilestoneEmbeddedViewer.dll.config** file, on the computer with the Milestone XProtect Smart Client. The file is located at: **C:\Program Files\Milestone\XProtect Smart Client\MIPPlugins\BriefCam.**
4. Add the following text under the <appSettings> node:
`<add key="InstallationType" value="SMB" />`
5. Save the file.
6. Log into XProtect Smart Client.

License upgrade

1. You now need to activate an upgraded license as follows:Generate a C2V File
2. Open the Chrome/Edge browser.
3. Go to <http://localhost:1947>.
4. Click the **Sentinel Keys** option.
5. From the **Actions** column, click **C2V**.




6. Log into the BriefCam Portal at <https://www.briefcam.com/support/> and open a ticket. You'll attach the C2V file and request a V2C file with the 2024M1 features.

The BriefCam Customer Success team will email you the requested V2C (vendor to client) file.


Apply the V2C File


1. Open the Chrome/Edge browser.
2. Go to <http://localhost:1947>
3. Click the **Update/Attach** option.
4. Click the **Choose File** button and select the V2C file that you received from BriefCam.
5. Click the **Apply File** button.



Restart Services and clear the cache

1. Launch the BriefCam Web Administrator Console and start the BriefCam services needed for each host.
2. Restart the IIS services on the computer where the BriefCam Web Services are installed:
 - Open the Windows services, right-click **World Wide Web Publishing Service**, and click **Restart**.



 After restarting the IIS services, it might take a minute or two to get results when filtering objects for the first time after the restart.

3. Clear the browser's cache.
4. To ensure that all the new features work as expected, reprocess previously processed videos.

Non-administrator users

After upgrading, if you want non-administrator users to be able log into the Milestone system and see BriefCam:

1. Install BriefCam's management client for the Milestone plug-in.
2. From the BriefCam server, open the MilestoneSSOProvider.exe.config file, which is located at: C:\Program Files\BriefCam\BriefCam Server\.
3. Delete the AllowedUserRole row or comment it out by adding <!-- to the beginning of the row and --> to the end of the row as showed in the example below:

```
<appSettings>  
  <add key="AuthenticatorAddress" value=http://localhost:8030/MilestoneSSO/ />  
  <add key="MilestoneAddress" value=http://localhost/ />  
  <!-- <add key="AllowedUserRole" value="BriefCam Users" /> -->  
</appSettings>
```

4. Save the file.


Troubleshooting

To troubleshoot issues with the installation, see the [Installation Troubleshooting on page 18](#) section.

Failed fetching camera plugins error

Symptom

In the Camera management section of the BriefCam Administrator Console when trying to add a directory, the Milestone Integration option is not available and the Failed fetching camera plugins error appears at the bottom of the screen.



Possible root causes

- A shadow AKKA service is running in the background.
- Ports are blocked in the firewall.
- An antivirus/anti-spam ware is preventing reading/writing to BriefCam folders.
- The BriefCam shared folder is missing sufficient read/write permissions.


- The permissions issue is possibly because of one of the following (but not limited to):
 - a. GPO applied on the server
 - b. Current logged in user lacking admin privileges
 - c. Antivirus/antimalware restriction
 - d. Target drive out of space

Solution


1. In the **Services** pane of the BriefCam Administrator Console, check that the PID is not constantly changing for **one or more** of the AKKA services:
 - Lighthouse
 - LPR Matching
 - BI Face Recognition
 - Face Recognition Matching
 - Filtering
2. If one or more of the AKKA service's PID is constantly changing, this may be because a shadow AKKA service is running in the background. In this case:
 - a. From the BriefCam Administrator Console, stop the BriefCam AKKA services.
 - b. From the Task Manager, stop the relevant service.
 - c. From the BriefCam Administrator Console, restart the services.

3. Check that the relevant port is opened in the firewall. You can do this using the Telnet command:

- In the Control Panel, go to **Programs and Features** (or **Programs**).
- Click **Turn Windows Features on or off**.



- Select the box for **Telnet Client**.
 - Click **OK**.
 - In the command prompt (type **CMD** in the Windows search box), type: **telnet <IP address of server>** and press **Enter**.
 - If you see a blank cursor, the connection is fine
4. Check the Data folder for sufficient permissions. The current logged in user should have read/write permissions.




5. Check the relevant log for errors. The logs can be found at: **C:\Program Files\BriefCam\BriefCam Server\logs**. You may find, for example, information that the AKKA service failed to start.

White screen displayed

Symptom

XProtect Rapid REVIEW was installed without any errors. However, the embedded client shows a white/blank screen.



Possible root causes

The root cause is often a networking issue (that can be caused by, but is not limited to, an incorrect configuration).

Before you proceed with the drill-down and the different troubleshooting procedures described below, perform the most basic checks of networking. Use Powershell TNC (TestNetConnection) to verify that port 80 is listening where the BOA is installed and that port 8030 is listening where the SSO provider is installed. The majority of instances where a white screen issue is encountered, will be resolved by a network/firewall modification, or by a BOA/SSO config file modification (BOA/SSO address correction in the relevant config file as detailed in the [Environment settings not configured properly on page 60](#) section).

Other items to check include:

- Milestone user permissions
- Server-side/client-side cache issues
- The BriefCam server or Milestone smart client computers have two NICs (Network interfaces)
- Missing XProtect Rapid REVIEW license
- Environment settings not configured properly

Solution

Milestone user permissions

In order to view the BriefCam tab embedded in the Milestone XProtect Smart Client, the user who accesses the client has to have at least 'Read' permissions defined on the Milestone Management Client.

1. In the Milestone XProtect Smart Client, check that the user accessing the XProtect Smart Client has Read permissions.

- If the user exists but does not have Read permissions – assign the user the necessary permissions.
- If the user does not exist:
 - a. Create the user by accessing XProtect Management Client. The user will be created automatically in BriefCam when the user accesses XProtect.

Do not manually create the user in the BriefCam Administrator Console. If the user is created manually and has the same user name in Milestone XProtect, you will see a white screen in XProtect Smart Client.


- b. You can log into the BriefCam Administrator Console's Users section and verify that the Milestone user is there with the type set to SAML.

2. Try to access the smart client using this user and check the BriefCam tab.



Note that by default the user who runs the BriefCam services is the BCUser. You may still see the white screen issue if the user configured as BCUser was disabled, for example, after moving to a domain. To solve this issue:

- From the Windows Services, try restarting the BriefCam VSService.
- If the service fails to start, then check the BCUser settings in the **Computer Management** console.



3. If the issue still is not solved, check the Milestone client-side logs at **C: \Users\[current user]\AppData\Roaming\BriefCam\Client\logs**.

Clearing Server/Client Cache

Sometimes on a system where not all the components were installed correctly and the embedded client previously showed a white screen, clearing the Milestone client cache can solve the issue.

To clear the cache on the BriefCam server-side:

1. Go to: **C:\Users\CurrentLoggedInUser\AppData\Roaming\Milestone**.



Note that the AppData folder is a hidden folder. If you do not have hidden folders enabled on your machine, you can open the AppData folder by going to the search bar on your Windows Toolbar, typing %appdata% and pressing Enter.

2. Delete all the contents of this folder.

The next time you start a Milestone XProtect client, the contents of this folder will be recreated.

To clear the cache on the XProtect Smart Client side:

- a. Go to: **C:\Users\CurrentLoggedInUser\AppData\Roaming\BriefCam\MilestoneEmbedded.**
- b. Delete all the contents of this folder.

The next time you start a Milestone XProtect client, the contents of this folder will be recreated.


Two NICs

The white screen might display if either the BriefCam server or Milestone smart client computer has two NICs (network interfaces) attached to it and the SSO communication looks for the local host.

As a result, there are issues loading BriefCam's iFrame in the Milestone embedded client.

To solve this issue:

1. Check how many activated NICs exist, by going to **Control Panel > Network and Sharing Center > Change adapter settings.**




2. If there is more than one NIC activated, if possible, inactivate one of the NICs.

If the above did not resolve the issue, you need to change the value in several locations so that it does not point to **localhost** but rather to the BriefCam server's IP address (the IP address of the NIC configured to communicate between the BriefCam server and the Milestone server):

3. On the BriefCam server, open the Milestone SSOProvider.exe.config file (located by default at: C:\Program Files\BriefCam\BriefCam Server) and find the **AuthenticatorAddress** value.
4. If the value is set to **localhost**, change the value to point to the Milestone server's IP address.

```

33     <assemblyIdentity name="System.Threading.Tasks.Extensions" publicKeyToken="cc7b13f
34     <bindingRedirect oldVersion="0.0.0.0-4.2.0.1" newVersion="4.2.0.1" />
35     </dependentAssembly>
36     <dependentAssembly>
37     <assemblyIdentity name="System.Numerics.Vectors" publicKeyToken="b03f5f7f11d50a3a"
38     <bindingRedirect oldVersion="0.0.0.0-4.1.4.0" newVersion="4.1.4.0" />
39     </dependentAssembly>
40     <dependentAssembly>
41     <assemblyIdentity name="System.Memory" publicKeyToken="cc7b13ffod2ddd51" culture="
42     <bindingRedirect oldVersion="0.0.0.0-4.0.1.1" newVersion="4.0.1.1" />
43     </dependentAssembly>
44     </assemblyBinding>
45     </runtime>
46     <appSettings>
47     <add key="AuthenticatorAddress" value="http://192.168.2.10:8030/MilestoneSSO/" />
48     <add key="MilestoneAddress" value="192.168.2.9" />
49     <!-- <add key="AllowedUserRole" value="BriefCam Users" /> -->
50     </appSettings>
51 </configuration>
    
```


 By default the MilestoneSSOProvider.log file is located at C:\Program Files\BriefCam\BriefCam Server\logs\MilestoneSSOProvider-0.

5. On the Milestone XProtect Smart Client computer, open the BriefCam.MilestoneEmbeddedViewer.dll.config file (located at: C:\Program Files\Milestone\XProtect Smart Client\MIPPlugins\BriefCam).
6. If the value of the **serverAddress** or **boaServerAddress** key is set to localhost, change the values to point to the BriefCam server's IP address.

```

158     <assemblyIdentity name="Microsoft.Extensions.Hosting.Abstractions"
159     <bindingRedirect oldVersion="0.0.0.0-3.1.3.0" newVersion="3.1.3.0" />
160     </dependentAssembly>
161     <dependentAssembly>
162     <assemblyIdentity name="System.Text.Json" publicKeyToken="cc7b13ffcc
163     <bindingRedirect oldVersion="0.0.0.0-4.0.1.1" newVersion="4.0.1.1" />
164     </dependentAssembly>
165     </assemblyBinding>
166     </runtime>
167     <appSettings>
168     <!-- Client site address -->
169     <add key="serverAddress" value="192.168.2.10/Synopsis/" />
170     <!-- Boa site address -->
171     <add key="boaServerAddress" value="http://192.168.2.10/BOA" />
172     <!--add key="boaVersion" value="1.0" /-->
173     <!--add key="keepAliveIntervalMS" value="60000" /-->
174     <!--add key="httpTimeout" value="5000" /-->
175     <!--add key="pageLoadTimeoutMS" value="1000" /-->
176     <!--add key="BrowserLogLocation" value="c:\DotNetBrowserLog.txt" /-->
177     </appSettings>
178     <startup><supportedRuntime version="v4.0" sku=".NETFramework,Version=v4.7.2"
    
```

7. In the BriefCam Administrator Console, go to **Settings > Environment settings** and search for the **SSOEndpoint** setting. If the value is set to **localhost**, change it to the BriefCam server's IP address, that is: `http://[BriefCam server IP address]:8030/Milestone`.



8. Restart the following:
 - a. In the BriefCam Administrator: the Milestone SSO Provider service and the VS Server service.
 - b. The BOA application pool of the IIS.
 - c. Milestone XProtect Smart Client.
9. Clear the cache as described in the [Clearing Server/Client Cache on page 57](#) section.

Missing license

The BriefCam Open API (BOA) is the communication between BriefCam and the Milestone SSO.

1. Check the BOA log at `C:\Logs\Milestone\BOA` – It could, for example, point to a missing license.
2. Check that the BOA license product exists at `localhost:1947`.

Environment settings not configured properly

In rare scenarios, you'll need to manually configure SSO-related settings making sure that each of the config file's settings are pointing to the proper server hostname.


1. In the BriefCam Administrator Console, go to **Settings > Environment settings** and search for the **SSOEndpoint** setting. If the value is set to **localhost**, change it to the BriefCam server's IP address, that is: `http://[BriefCam server IP address]:8030/Milestone`.
2. Open the `MilestoneSSOProvider.exe.config` file (located at: `C:\Program Files\BriefCam\BriefCam Server`) and find the **AuthenticatorAddress** value.
3. If the value is set to **localhost**, change the value to the BriefCam server. If there are multiple NICs, this should point to the Milestone server.

4. In the BriefCam.MilestoneEmbeddedViewer.dll.config file (located at: C:\Program Files\Milestone\XProtect Smart Client\MIPPlugins\BriefCam), both the **serverAddress** and the **boaServer** address need to point to the BriefCam server. If there is more than one NIC, use the IP address of the BriefCam server. Below are detailed instructions of how to do this:
 - a. Scroll to the bottom of the file and look for the following lines: `<add key="serverAddress" value="http://computer's_hostname/synopsis/" />`
 - b. Change the values to match your BriefCam server (the XPRR Computer). For example, if the BriefCam XPRR computer is called RapRev, the value will look as follows: `http://RapRev/synopsis/`
 - c. Find this row: `<add key="boaServerAddress" value="http://cmputer's_hostname/BOA/" />`
 - d. Change the value point to your Milestone server. For example: `http://RapRev/BOA/`
5. Restart the following:
 - a. In the BriefCam Administrator: the Milestone SSO Provider service and the VS Server service.
 - b. The BOA application pool of the IIS.
 - c. Milestone XProtect Smart Client.
6. Clear the cache as described in the [Clearing Server/Client Cache on page 57](#) section.

Server unavailable error

Symptom

After installing BriefCam and trying to open the BriefCam Administrator Console, a Server Unavailable error appears. When opening F12 (debug mode), the following is seen:




Possible root causes

- BriefCam and Milestone are installed on the same computer, which causes the IIS services to conflict since the same ports are in use. As detailed in the prerequisites, a dedicated machine for BriefCam is required.
- The IIS components are not configured on the current server. This may be because of a custom operating system image that includes certain restrictions, such as the IIS is not installed, only a restricted list of components was installed, or the Sysadmin restricted those components to be installed/configured by external installers.

Solution

1. From the Windows Control Panel, open Programs and Features.
2. Click **Turn Windows features on or off**.
3. From the list, make sure that all the Internet Information Services that appear in the illustration below are available.
 - If any of the below is missing, add it.
 - Restart the computer.



Server returned 401 Unauthorized error

When trying to get a live stream from the Milestone VMS, the “Server returned 401 Unauthorized (authorization failed)” error may occur when you have, for example, more than one WWW-Authenticate header. This can occur in XProtect 2021 R1 and above.

To solve this issue:

1. Make sure you are using the following Milestone ONVIF Bridge component: VideoOS.ONVIF.InstallerForExpressAndProfessional.exe Version 21.1b build 7008. For a detailed step-by-step guide, see <http://download.milestonesys.com/MTSKB/KB000003403/ONVIF-Bridge-detailed-guide.pdf>.
2. Open the Windows Registry (click **Windows + R**, type **regedit**, and press **Enter**).
3. Open the following registry:
`Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Milestone\Milestone Open Network Bridge\`
4. Add the following DWORD value: **SHA256Auth**.
5. Set the value to 0.
6. In the ONB Tray Manger, restart the ONB services.

This registry, introduced with XProtect 2021 R1, switches off SHA256 support, when FIPS is disabled.

For additional information, see: <https://developer.milestonesys.com/s/article/changes-digest-authentication-RTSP-service-in-2021-R1-troubleshooting>.

Rapid REVIEW tab is missing

Symptom

The Rapid REVIEW tab is missing from the Milestone XProtect embedded client.

Possible root causes

- Visual Studio X64 redistributable package is not installed. This can be caused by a GPO or other restrictions applied by the System Administrator.
- Windows is not up to date (even though this is one of the prerequisites).

Solution

1. On the XProtect Smart Client computer, download the vc_redist.x64.exe runtime component for Visual C++: [Microsoft Download Center](#).

2. Run the executable file as Admin.
3. Clear the cache on the Milestone XProtect Smart Client side:
 - a. Go to: C:\Users\CurrentLoggedInUser\AppData\Roaming\Milestone\BriefCam\Milestone Embedded.



Note that the **AppData** folder is a hidden folder. If you do not have hidden folders enabled on your machine, you can open the **AppData** folder by going to the search bar on your Windows toolbar, typing **%appdata%** and pressing Enter.

- b. Delete all the contents of this folder. The next time you start a Milestone XProtect client, the contents of this folder will be re-created.
 - c. Access the Milestone XProtect embedded client.
4. If this does not work, install the latest Windows update.

Rapid REVIEW tab is not appearing correctly

If you are upgrading from v6.1, the tab name will not show Rapid REVIEW. To change the tab name:

1. Open the BriefCam.MilestoneEmbeddedViewer.dll.config file, which is located at: C:\Program Files\Milestone\XProtect Smart Client\MIPPlugins\BriefCam\.
2. Add the following text under the <appSettings> node:
<add key="InstallationType" value="SMB" />
3. Save the file.

APPENDIX: XProtect Rapid REVIEW 2024 M1 hardware recommendations

This section aims to assist in selecting hardware for a system that will run XProtect Rapid REVIEW.

At the core of these systems are the graphical processing units (GPUs) that are responsible for processing the original video and extracting metadata. The number/type of GPUs, the resolution of the original video, frame rate, and activity determine the number of hours of original video that can be processed per day (or per hour).

The more GPUs (and processing servers) a system has, the more original video it can process in an hour.

In addition to the GPUs, the system also relies on the CPU to support this video processing and the investigations that follow the processing – when the user filters through the various objects, measures proximity, and plays a VIDEO SYNOPSIS®.

The all-in-one, single server systems, cover a range of CPUs and a number of GPUs (from 1 to 4).

For systems that require more GPUs, BriefCam offers distributed architecture where the GPUs are located on dedicated Processing Servers alongside additional servers that run the BriefCam services (such as perform filtering and play a VIDEO SYNOPSIS®).

These hardware specs can be defined by their processing throughput (the number of hours of original video that can be processed within an hour of processing or per day). These are measured under certain input video characteristics, such as resolution and activity level.

When we refer to an activity level, we refer to the number of objects that pass through the scene in an hour, under certain movement patterns.

We benchmarked the throughputs in this document under medium activity – which refers to roughly 1,000 objects (people and vehicles detected by the analytics engine) per hour.

The throughputs listed below each hardware spec relate to the throughput of the machine (based on the throughput of the GPUs) – the VMS and network architecture and infrastructure need to support this throughput as well.

Several users can use the system concurrently, but this will increase the load on the system. Our recommendations and design assumptions are for a maximum of 2 concurrent users.

Face Recognition and License Plate Recognition Watchlist searches require resources. Our recommendations assume watchlists of less than 10,000 identities in total (across all of the used watchlists combined).

All-in-One configurations

This section aims to assist in selecting hardware for a system that runs XProtect Rapid REVIEW in All-in-One Configurations.

System size			Medium	Medium	Large	Extra-Large
Form Factor			Tower	1U	2U	2U
CPU			Latest Intel i9	Latest Intel i9	2 x Xeon Silver	2 x Xeon Gold
Memory (GB)			128	128	128	256
GPU			1 x RTX A2000	1 x RTX A4000	2 x RTX A4000	4 x RTX A4000
Hard Drives						
No.	Type	Purpose				
1	SSD (GB)	Operating System	256	256	480	480
2	Mixed Use SSD (GB)	Database	480	480	1000	2000
3+	HDD (TB)	Processed Video	8	8	2 x 8	4 x 8
Throughput						
At 1080p Medium activity			Up to 23 hours per hour (552 hours per day)	Up to 28 hours per hour (672 hours per day)	Up to 46 hours per hour (1,104 hours per day)	Up to 92 hours per hour (2,208 hours per day)
At 4K Medium activity			Up to 6 hours per hour (192 hours per day)	Up to 6 hours per hour (192 hours per day)	Up to 12 hours per hour (408 hours per day)	Up to 24 hours per hour (816 hours per day)

Throughput example

24 hours of original 1080p video at medium activity will take about 2.5 hours with the small build, 1 hour with the medium build, 30 minutes with the large build, and 15 minutes with the extra-large build.

RAID redundancy

If bays are available, RAID1 redundancy can be applied with extra OS and DB drives, if desired.

Larger deployments

For larger deployments, please consult your local Milestone representative.

Supported Graphical Processing Units (GPU)

The GPUs listed below have undergone thorough testing and certification by BriefCam, accompanied by throughput benchmarking conducted by our organization:

CERTIFIED NVIDIA GPUs	
GPU	Certified
Ampere A10	Yes
Ampere RTX A2000	Yes
Ampere RTX A4000	Yes



Intel, AMD or any other non-NVIDIA GPUs are not supported at this time.



Using more than one type of GPU on the same computer is not supported, and the new Ada Lovelace Architecture by NVIDIA is not supported either. GPUs utilizing this architecture will not be compatible with the BriefCam's platform.

Other GPUs

While XProtect Rapid REVIEW is validated to run with most Nvidia GPUs, performance may vary, and the reliability of the analytics may also suffer from an underperforming GPU.

There is no guarantee regarding the performance of GPUs which are not listed as certified in the above list.



helpfeedback@milestone.dk

About Milestone

Milestone Systems is a leading provider of open platform video management software; technology that helps the world see how to ensure safety, protect assets and increase business efficiency. Milestone Systems enables an open platform community that drives collaboration and innovation in the development and use of network video technology, with reliable and scalable solutions that are proven in more than 150,000 sites worldwide. Founded in 1998, Milestone Systems is a stand-alone company in the Canon Group. For more information, visit <https://www.milestonesys.com/>.

